



Gatekeeper Setup for ViewStations

From the main Menu Screen:

- 1) Arrow to the top left option and select “System Info”
- 2) System Information Menu - Arrow over the far left for “Admin Setup” (The password should be 3728, if asked)
- 3) Admin Setup Menu – Arrow to “LAN/H323” menu.
- 4) LAN/H323 Menu – Arrow to “H.323” menu.
- 5) H.323 Setup Menu – Arrow to “Gatekeeper” menu.
- 6) Gatekeeper Menu:
 - a. H.323 Name – This is the name other systems will dial, if dialing by name. If you have more than one camera at your district, please identify by campus.
 - b. H.323 Extension (E.164) – This is another way of dial others on the network registered to the gatekeeper; much easier. Please use the numeric table provided for you district listed below. If you have more than one camera, please assign them accordingly. Every district has 100 numeric options. Example: Region8 has 8000-8099. reg8rm1 is 8001 extension.
 - c. Use Gatekeeper – select specify
 - d. Gatekeeper IP Address – 10.44.36.249 (External IP address is 66.76.71.249 for external access inside)
- 7) There will be some test extension listed below and posted on the Distance Learning Web site.